

Designer GLASS SIGNS

ClickFix

Click Fix signs consist of a stainless steel back plate, a white cardboard insert, the printing film with your sign information on it and a non reflecting acrylic glass cover.

Click Fix signs can be mounted with screws or double sided tape.

The information on the sign can easily be changed. A rubber suction cup is used to remove the acrylic cover and then the printing film can be exchanged.


Available Sizes

150 x150 mm (6" x 6")

210 x 297 mm (8 1/4" x 11 3/4")

150 x 210 mm (6" x 8 1/4")

297 x 420 mm (11 3/4" x 16 1/2")



GlasFix

Glass Fix signs consist of a stainless steel back plate, a white cardboard insert, the printing film with your sign information on it and a tempered glass cover.

Due to the u shape of the stainless steel frames at the top and bottom, the glass plate easily slides into place.

Glass Fix signs can be mounted with screws or double sided tape.

The information on the sign can easily be changed. A rubber suction cup is used to remove the glass cover and then the printing film can be exchanged.

Available Sizes

150 x150 mm (6" x 6")

210 x 297 mm (8 1/4" x 11 3/4")

150 x 210 mm (6" x 8 1/4")

297 x 420 mm (11 3/4" x 16 1/2")



These sizes are available for horizontal and vertical mounting.